


<b>GB</b>	<b>INSTRUCTIONS FOR USE</b>	
<b>PRODUCT DESCRIPTION</b>		<b>PAGE 11</b>
<b>REPLACING BULBS</b>		<b>PAGE 11</b>
<b>BEFORE USING THE REFRIGERATOR</b>		<b>PAGE 12</b>
<b>SAFEGUARDING THE ENVIRONMENT</b>		<b>PAGE 12</b>
<b>PRECAUTIONS AND GENERAL RECOMMENDATIONS</b>		<b>PAGE 12</b>
<b>HOW TO OPERATE THE REFRIGERATOR COMPARTMENT</b>		<b>PAGE 13</b>
<b>HOW TO DEFROST THE REFRIGERATOR</b>		<b>PAGE 14</b>
<b>CARE AND MAINTENANCE</b>		<b>PAGE 14</b>
<b>TROUBLESHOOTING GUIDE</b>		<b>PAGE 15</b>
<b>AFTER-SALES SERVICE</b>		<b>PAGE 15</b>
<b>INSTALLATION</b>		<b>PAGE 15</b>
<b>ELECTRICAL CONNECTION</b>		<b>PAGE 16</b>

## PRODUCT DESCRIPTION




- A** Low temperature compartment
- B** Low temperature compartment door
- C** Water collection tray
- D** Adjustable shelves and grids
- E** Crisper drawer
- F** Temperature adjustment thermostat
- G** Rating plate (at the side of the crisper drawer)
- H** Adjustable foot
- I** Door seal spacers for transport purposes (remove and discard)

## REPLACING BULBS

### Replacing bulbs

1. Press as shown in the figure.
2. Pull towards the inside of the appliance.
3. Replace the bulb (max 15W).



## BEFORE USING THE REFRIGERATOR

- Your new appliance is exclusively for domestic use.
- The **low temperature compartment** can be used to make ice cubes.
- **Defrosting is a manual or semi-automatic procedure.** The **refrigerator compartment** is designed for the storage of fresh food and beverages.
- To get the most out of your new appliance, read the user handbook thoroughly. The handbook contains a description of the appliance and useful tips for storing food.
- Discard the door seal spacer shown at point I of the figure.
- Keep this handbook for future consultation.
- After unpacking the appliance, make sure that the door shuts properly. Any damage must be reported to your dealer within 24 hours after delivery of the appliance.
- **Wait at least two hours before connecting the appliance to the power supply in order to ensure the refrigerant circuit is fully efficient.**
- Installation of the appliance and electrical connections must be carried out by a qualified electrician, in accordance with the manufacturer's instructions and local regulations.

## SAFEGUARDING THE ENVIRONMENT

### 1. Packing

The packaging material is entirely recyclable, and marked with the recycling symbol. Follow local regulations for scrapping.

Keep the packaging materials (plastic bags, polystyrene parts, etc.) out of reach of children, as they are potentially dangerous.

### 2. Appliance

The appliance is made using recyclable materials. Dispose of the appliance in conformity with local environmental regulations.


Make the appliance unusable by cutting off the power cord. The appliance must be delivered to an authorised collection centre for the recovery of refrigerant gas.

### Information:

This appliance does not contain CFCs (replaced with R134a) or HFCs (replaced with R600a - Isobutane). For more information, refer to the identification data plate affixed to the appliance.

### Appliances with Isobutane (R600a)

Isobutane is a natural gas having low environmental impact. Caution is required, however, since isobutane is flammable. Therefore, it is essential to ensure that refrigerant pipelines are not damaged.



## PRECAUTIONS AND GENERAL RECOMMENDATIONS

- Use the **refrigerator compartment** only for storing fresh foods and the **low temperature compartment** only for making ice cubes.
- Do not cover or obstruct the air vents of the appliance.
- Do not store liquids in glass containers in the low temperature compartment - risk of bursting.
- Do not eat ice cubes or ice lollies immediately after taking them out of the low temperature compartment - risk of "cold" burns.
- Do not allow children to play or hide inside the appliance - risk of becoming trapped and suffocating.
- Before servicing or cleaning the appliance, unplug it from the mains or disconnect the electrical power supply.
- The power cable may only be replaced by an authorised person.

### Declaration of conformity

This appliance is intended to come into contact with foodstuffs and conforms to D.L. 108 of 25.01.1992 (European Directive 89/109/EEC).

## HOW TO OPERATE THE REFRIGERATOR COMPARTMENT

### Switching on the appliance

#### Starting up the appliance

- Plug in the appliance.
- The inside light, where provided, switches on when the refrigerator door is opened.

#### Adjusting the temperature

**Ensure the water collection tray, located below the low temperature compartment, touches the rear wall of the refrigerator unit.**

The thermostat, located on the right hand side of the refrigerator compartment, is used to adjust the internal temperature.

To adjust the temperature in the refrigerator compartment, turn the thermostat control knob:

- Lowest numbers **1-2** for the **LEAST COLD** internal temperatures;
- Numbers **3-4** for a **MEDIUM** internal temperature;
- Highest numbers **5-7** for the **COLDEST** internal temperatures.



Thermostat set to ● or ✱: the appliance is switched off although it remains connected to the mains power supply.

#### Note:


The ambient air temperature, the frequency of door opening and the position of the appliance can affect internal temperatures. These factors must be taken into account when setting the thermostat.

#### Position of water collection tray:

when the room temperature is above 25°C, pull the water collection tray forwards, aligning it with the two small dots on the right-hand side of the refrigerator unit (**Fig. 1**).



(Fig. 1)



### Using the refrigerator compartment

Position food as follows:

- A **Cooked foods, cakes, soup/pasta:** on the grid below the low temperature compartment.
- B **Fish, meat, cold cuts:** on the grid above the crisper drawer.
- C **Fruit and vegetables:** in the special crisper drawer.
- D **Bottles, canned produce:** use the door trays in the inner door.
- E **Eggs:** use the special compartment in the inner door.

#### Notes:

- The space between the shelves and the rear wall of the refrigerator compartment must be unobstructed to allow circulation of air.
- Do not place food in direct contact with the rear wall of the refrigerator compartment.
- Do not place hot food in the refrigerator.
- Store liquids in closed containers.

## HOW TO DEFROST THE REFRIGERATOR

Defrost the appliance when the ice on the walls reaches a thickness of about 3 mm.

Ensure the water collection tray is empty and properly positioned below the low temperature compartment.

### Semi-automatic defrost (Fig. 1)

- Press the button (A) in the middle of the thermostat knob and close the door. Once all the ice has melted, the button will return to its original position and the refrigerator will automatically start functioning again.


### Manual defrost (Fig. 2)

For appliances without defrost button:


- Turn the thermostat knob to the defrost position.
- After defrosting, turn the knob back to its original position.

It is not necessary to empty the rest of the refrigerator.

**Do not use sharp objects or metal instruments to remove ice.**



(Fig. 1)



(Fig. 2)

## CARE AND MAINTENANCE


**Before any cleaning or maintenance operation, unplug the appliance from the mains or disconnect the electrical power supply.**

- Clean the interior periodically with a sponge soaked in warm water and/or neutral detergent. Do not use abrasive substances.
- Rinse the interior and dry thoroughly.
- Clean the inside of the low temperature compartment when defrosting.
- Clean the outside with a damp cloth. Do not use abrasive products, scourers, stain-removers (e.g. acetone, trichloroethylene) or vinegar.
- Periodically clean air vents and the condenser at the rear of the appliance with a vacuum cleaner or a brush.

### Prolonged disuse

- Empty the refrigerator.
- Disconnect the appliance from the power supply.
- Defrost and clean the interior.

- In the event of prolonged disuse, leave the door open to prevent the formation of mould, odours and oxidation.
- Clean the appliance.



## TROUBLESHOOTING GUIDE

- 1. The appliance is not working.**
  - Is there a power failure?
  - Is the power cord in perfect condition?
  - Is the plug properly inserted in the socket?
  - Has the fuse blown?
  - Is the thermostat set to ● (Stop) or ✱ (defrost)?
- 2. Temperature inside the compartments is not low enough.**
  - Is the door shut properly?
  - Is there an excessive frost build-up in the low temperature compartment?
  - Is the appliance installed near a heat source?
  - Is the thermostat setting correct?
  - Are the air circulation vents blocked?
- 3. Temperature inside the refrigerator compartment is too low.**
  - Is the thermostat setting correct?
- 4. The appliance is excessively noisy.**
  - Has the appliance been installed correctly?
  - Are the pipes at the back touching or vibrating?
- 5. Water collects at the bottom of the refrigerator compartment.**
  - Is the thermostat setting correct?
- 6. The inside light is not working**
  - Is there a power failure?
  - If not, unplug the appliance from the mains, remove the cover and check the bulb has not come loose. If necessary, replace the bulb with a new one (max 15 W).

### Notes:

- Gurgling and hissing noises due to expansion in the refrigerant circuit are normal.

## AFTER-SALES SERVICE

### Before contacting After-Sales Service:

1. See if you can solve the problem yourself with the help of the "Troubleshooting Guide".
2. Switch the appliance on again to see if the problem has been solved. If it has not, disconnect the appliance from the power supply and wait for about an hour before switching on again.
3. If the problem persists after this course of action, contact After-sales Service.

### Specify:

- The nature of the problem.
- The model.
- The Service number (the number after the word SERVICE on the data plate on the inside of the appliance).

**SERVICE** 0000 000 00000



- Your full address.
- Your telephone number and area code.

## INSTALLATION

- Install the appliance away from heat sources. Installation in a hot environment, direct exposure to the sun or installation near heat sources (heaters, radiators, cookers) will increase power consumption and should therefore be avoided.
- Leave at least 5 cm clearance above the appliance and ensure any adjacent units allow sufficient space for air circulation.
- Install the appliance in a dry, well-ventilated place, and ensure it is level, using the front adjustment foot if necessary.
- Ensure the air circulation grille on top of the appliance is unobstructed in order to guarantee circulation of air.
- Clean the interior and fit the accessories supplied.
- Fill the ice cube tray (if provided) with water and place it in the low temperature compartment.


### Electrical connection

- **Electrical connections must be made in accordance with local regulations.**
- Voltage and power consumption are indicated on the rating plate inside the appliance at the bottom left hand side, at the side of the crisper drawer.
- **Regulations require that the appliance is earthed. The manufacturer declines all liability for injury to persons or animals and for damage to property resulting from failure to observe the above procedures and reminders.**
- If the plug and socket are not of the same type, have the socket replaced by a qualified electrician.

Do not use extension leads or adaptors.

## ELECTRICAL CONNECTION

### For Great Britain only



The wires in the mains lead are coloured in accordance with the following code:

BLUE - "NEUTRAL" ("N")

BROWN - "LIVE" ("L")

GREEN AND YELLOW - "EARTH" ("E")

1. The GREEN AND YELLOW wire must be connected to the terminal in the plug which is marked with the letter "E" or by the Earth symbol  $\frac{\perp}{\text{—}}$  or coloured green or green and yellow.
2. The BLUE wire must be connected to the terminal which is marked with the letter "N" or coloured black.
3. The BROWN wire must be connected to the terminal which is marked with the letter "L" or coloured red.

### Warning - this appliance must be earthed

#### Fuse replacement

If the mains lead of this appliance is fitted with a BS 1363A 13amp fused plug, to change a fuse in this type of plug use an A.S.T.A. approved fuse to BS 1362 type and proceed as follows:

1. Remove the fuse cover (A) and fuse (B).
2. Fit replacement 13A fuse into fuse cover.
3. Refit both into plug.

#### Important:

The fuse cover must be refitted when changing a fuse and if the fuse cover is lost the plug must not be used until a correct replacement is fitted.


Correct replacement are identified by the colour insert or the colour embossed in words on the base of the plug.

Replacement fuse covers are available from your local electrical store.

#### Connection to a rewirable plug

If the fitted plug is not suitable for your socket outlet, then it should be cut off and disposed of in order to avoid a possible shock hazard should it be inserted into a 13A socket elsewhere.

A suitable alternative plug should then be fitted to the cable.



### For the Republic of Ireland only

- The information given in respect of Great Britain will frequently apply, but a third type of plug and socket is also used, the 2-pin, side earth type. In this case, the wire which is coloured GREEN AND YELLOW must be connected to the EARTH contact, and the two wires to the two pins, irrespective of colour. The supply to the socket must be fitted with a 16 amp fuse.